

TPMS TOOL VT06



USER MANUAL VT06

DESCRIPTION

The VT06 “wakes up” tire pressure monitoring system (TPMS) sensors mounted to the vehicle’s wheel.

FUNCTION

The VT06 sends a RF signal to the TPMS sensor mounted to the vehicle’s wheel to “wake up” the sensor. Once the tool triggers the sensor, the sensor is ready to communicate with the vehicle’s ECU.

TOOL COMPATIBILITY

The VT06 is compatible with the TPMS sensors listed at the end of the manual.

INSTRUCTIONS

While holding the tool next to the side wall of the tire above the sensor, press and hold the button to trigger the sensor (You can also press the tool directly against the sidewall of the tire). An orange light will illuminate on the tool. Continue to hold the button down until successful signal transfer to the vehicle’s ECU, diagnostic station or until the vehicle’s horn “beeps”.

BATTERY INSTALLATION

Open the plastic case by removing the two screws.

Connect the 9 Volt battery to the internal connector.

Close the plastic case with the two screws. Do not put the battery in the bin.



Make	Model	Year
Alfa Romeo	4C	2013-2019
Alfa Romeo	MiTo 2	2013-2016
Aston Martin	DBS Superleggera	2018
BMW	5 Series (G30 G31)	2017-2019
BMW	7 Series (G11 G12)	2016-2019
BMW	M5	2018-2019
BMW	X3 (G01)	2017-2019
BMW MOTORCYCLE	ALL	2007-2018
Buick	Allure	2007-2011
Buick	Cascada	2016-2019
Buick	Enclave	2008-2019
Buick	Encore	2013-2019
Buick	Envision	2015-2019
Buick	LaCrosse	2006-2019
Buick	LeSabre	2007
Buick	Lucerne	2007-2011
Buick	Regal	2011-2019
Buick	Verano	2012-2018
Cadillac	ATS	2013-2019
Cadillac	CT6	2016-2019
Cadillac	CTS	2008-2019
Cadillac	Deville	2001-2005
Cadillac	DTS	2006-2011
Cadillac	ELR	2014-2016
Cadillac	Escalade	2001-2006
Cadillac	Escalade	2007-2019
Cadillac	Seville	2001-2004
Cadillac	SRX	2007-2016
Cadillac	STS	2005-2008
Cadillac	STS	2009-2011
Cadillac	XLR	2004-2009
Cadillac	XT4	2019
Cadillac	XT5	2017-2019
Cadillac	XTS	2013-2019
Chevrolet	Avalanche	2004-2006
Chevrolet	Avalanche	2007-2013
Chevrolet	Aveo	2002-2011
Chevrolet	Aveo	2018
Chevrolet	Bolt EV	2017-2019
Chevrolet	Camaro	2010-2019
Chevrolet	Caprice	2011-2017
Chevrolet	Captiva Sport	2012-2017
Chevrolet	Cobalt	2008-2010
Chevrolet	Colorado	2006-2012
Chevrolet	Colorado	2015-2019
Chevrolet	Corvette	1997-2000
Chevrolet	Corvette	2001-2004

Chevrolet	Corvette	2005-2009
Chevrolet	Corvette	2010-2019
Chevrolet	Cruze	2011-2019
Chevrolet	Equinox	2007-2019
Chevrolet	Express Series	2007-2019
Chevrolet	HHR	2008-2011
Chevrolet	Impala	2006-2019
Chevrolet	Malibu	2008-2019
Chevrolet	Monte Carlo	2006-2007
Chevrolet	Orlando	2012-2014
Chevrolet	Silverado	2004-2006
Chevrolet	Silverado	2007-2019
Chevrolet	Sonic	2012-2019
Chevrolet	Spark	2012-2019
Chevrolet	SS	2014-2017
Chevrolet	Suburban	2004-2006
Chevrolet	Suburban	2007-2019
Chevrolet	Tahoe	2004-2006
Chevrolet	Tahoe	2007-2019
Chevrolet	Traverse	2009-2019
Chevrolet	Trax	2013-2019
Chevrolet	Uplander	2008-2009
Chevrolet	Volt	2010-2019
Chrysler	300	2009-2019
Chrysler	300M	2002-2004
Chrysler	Concorde	2002-2004
Chrysler	Crossfire	2004-2008
Chrysler	Intrepid	2002-2004
Chrysler	Pacifica	2004
Chrysler	Prowler	2001-2002
Chrysler	Town & Country	2002-2003
Chrysler	Town & Country	2011-2016
Chrysler	Voyager	2002-2003
Dodge	C/V	2012-2016
Dodge	Caravan	2002-2003
Dodge	Challenger	2008-2019
Dodge	Charger	2009-2019
Dodge	Durango	2011-2015
Dodge	Grand Caravan	2001-2003
Dodge	Grand Caravan	2011-2019
Dodge	Intrepid	2002-2004
Dodge	Journey	2011-2019
Dodge	Viper	2003-2010
Dodge	Viper	2013-2018
Fiat	500	2011-2019
Fiat	500L	2014-2019
Fiat	500E	2016
Ford	EcoSport	2018-2019

Ford	Edge	2015-2019
Ford	Expedition	2003-2006
Ford	Expedition	2018
Ford	Explorer	2002-2005
Ford	Explorer	2016-2019
Ford	Fiesta	2018-2019
Ford	Focus RS	2016-2018
Ford	Freestar	2004-2005
Ford	F-Series	2015-2019
Ford	F-Series Super Duty	2017-2019
Ford	Fusion	2017-2019
Ford	GT	2017-2019
Ford	Mustang	2015-2019
Ford	Ranger	2019
Ford	Transit	2019
Freightliner	Sprinter	2014-2018
Genesis	G70	2018-2019
GMC	Acadia	2007-2019
GMC	Canyon	2007-2012
GMC	Canyon	2013-2019
GMC	Savana	2008-2019
GMC	Sierra All	2004-2007
GMC	Sierra All	2007-2019
GMC	Terrain	2010-2019
GMC	Yukon All	2004-2006
GMC	Yukon All	2007-2019
Hummer	H2	2007-2009
Hummer	H3	2006-2010
Hyundai	Santa Fe	2019
Hyundai	Sonata	2015-2018
Hyundai	Tucson	2016-2018
Infiniti	QX30	2017-2018
Isuzu	i-290 / i-370	2007-2011
Isuzu	Rodeo	2004
Jeep	Grand Cherokee	2001-2004
Jeep	Grand Cherokee	2011-2015
Jeep	Liberty	2002-2004
Jeep	Wrangler	2013-2019
Kia	Stinger	2018-2019
Lincoln	Aviator	2003-2005
Lincoln	Continental	2017-2019
Lincoln	MKC	2018-2019
Lincoln	MKX	2016-2019
Lincoln	MKZ	2017-2019
Lincoln	Navigator	2003-2006
Lincoln	Navigator	2018-2019
Lincoln	Nautilus	2019
Lotus	Elise	2008-2011

Lotus	Evora	2010-2014
Lotus	Exige	2008-2011
Maserati	Ghibli	2013-2019
Maserati	Quattroporte	2014-2019
Mercedes	AMG GT	2016-2019
Mercedes	B Class	2014-2018
Mercedes	C Class	2008-2019
Mercedes	CL Class	2010-2014
Mercedes	CLA Class	2014-2019
Mercedes	CLK Class	2006-2009
Mercedes	CLS Class	2012-2018
Mercedes	E Class	2010-2017
Mercedes	E Class	2018-2019
Mercedes	G Class	2007-2018
Mercedes	GL Class	2010-2018
Mercedes	GLA Class	2015-2019
Mercedes	GLC Class	2016-2019
Mercedes	GLE Class	2016-2019
Mercedes	GLK Class	2010-2017
Mercedes	GLS Class	2017-2019
Mercedes	M Class	2010-2015
Mercedes	Metris	2016-2018
Mercedes	R Class	2010-2012
Mercedes	S Class	2010-2019
Mercedes	SL Class	2013-2019
Mercedes	SLC Class	2017-2018
Mercedes	SLK Class	2008-2018
Mercedes	SLS Class	2011-2015
Mercedes	Sprinter	2013-2018
Mercury	Monterey	2004-2005
Mercury	Mountaineer	2002-2005
Mitsubishi	Eclipse	2006-2012
Mitsubishi	Endeavor	2004-2011
Mitsubishi	Galant	2004-2012
Mitsubishi	Montero	2003-2006
Plymouth	Prowler	1997-2002
Pontiac	G3	2009-2010
Pontiac	G5	2008-2010
Pontiac	G6	2008-2010
Pontiac	G8	2008-2009
Pontiac	Grand Prix	2007-2008
Pontiac	Montana-SV6	2008-2009
Pontiac	Solstice	2008-2010
Pontiac	Torrent	2007-2009
Ram	Promaster	2014-2019
Ram	1500	2010-2013
Ram	1500	2019
Ram	2500	2010-2013

Ram	3500	2010-2013
Ram	3500 Dually	2010-2013
Ram	4500	2010-2013
Ram	5500	2010-2013
Retrofit	SCH-BRK-4PC	2017
Retrofit	SCH-WRK-4PC	2017
Retrofit	SCHRFK4S	2018
Rolls Royce	Cullinan	2018-2019
Rolls Royce	Phantom	2017-2019
Saab	9-3	2004-2007
Saab	9-3	2008-2012
Saab	9-4X	2011
Saab	9-5	2004-2007
Saab	9-5	2008-2009
Saab	9-5	2010-2012
Saturn	Astra	2008-2009
Saturn	Aura	2007-2010
Saturn	Outlook	2007-2010
Saturn	Sky	2008-2009
Saturn	Vue	2007-2010
Smart	Fortwo	2008-2017
Subaru	Ascent	2019
Subaru	B9 Tribeca	2006-2007
Subaru	Crosstrek	2015-2017
Subaru	Crosstrek	2018-2019
Subaru	Forester	2008-2017
Subaru	Forester	2018-2019
Subaru	Impreza	2008-2016
Subaru	Impreza	2017-2019
Subaru	Impreza WRX	2009-2017
Subaru	Impreza WRX	2018-2019
Subaru	Impreza WRX STI	2009-2019
Subaru	Legacy	2004-2017
Subaru	Legacy	2018-2019
Subaru	Outback	2004-2017
Subaru	Outback	2018-2019
Subaru	Tribeca	2008-2014
Subaru	XV Crosstrek	2013-2016
Suzuki	Forenza	2007-2008
Suzuki	Grand Vitara	2005-2013
Suzuki	Reno	2007-2008
Suzuki	SX4	2007-2013
Suzuki	Verona	2005-2006
Suzuki	XL-7	2005-2006
Suzuki	XL-7	2007-2009
Volvo	S60	2004-2009
Volvo	S80	2004-2006
Volvo	V70	2004-2007

Volvo	XC60	2009-2010
Volvo	XC70	2004-2007
Volvo	XC90	2004-2014