

RENEWING YOUR SOFTWARE LICENSE

visit www.ateq-tpms.com for more info



CONTACT SUPPORT

North America

888-621-8767 (En)

877-666-5325 (En/Fr)

help@supporttpms.com

Europe


emea-tpms-tech-support@ateq.com

1




If you do not already have the WebVT update software installed. Visit: webvt.ateq-tpms.com
If Installed, skip to step 5

2




Select the location on your PC that you wish to save the WebVT file.

3




Once the download is finished, locate the file and double-click the WebVT.exe icon.

4




Follow the instructions in the installation file to finish installing WebVT.

5




Once finished, a shortcut will appear on your PC desktop. double-click WebVT.

6



Connect your tool to your PC via USB cable. Once connected, all of the tool's information will be displayed, including the software subscription date.

7



At the top of the screen, select the "Renew License" icon.

8



A Popup will appear instructing you to enter the software license code. Once entered, press OK. Your software license subscription will be updated and the new subscription date will appear in "TPMS tool information".